



**LEGEND**

GRN • GREEN	---
YEL • YELLOW	---
BRN • BROWN	---
BLU • BLUE	---
BLK • BLACK	---
WHT • WHITE	---
RED • RED	---
ORG • ORANGE	---
GRY • GRAY	---

- NOTES**
- ① Neutral switch bypass UNPLUGGED (Emergency starting ONLY)
  - ② Oil Psi switch wire connect to Wire harness plug on engine side

I am not responsible for loss or damage due to the use or misinterpretation of this diagram!!!

**IMPORTANT:**  
Schematic is for reference Only  
**M.B. Sport H and V CDI Remote Steer**

Wiring Diagram		REV. NO.	N/A
FOR REFERENCE ONLY!			
DATE	SCALE	REV.	
TIKITIKI	N.T.S.	04-14-2012	
EXTEN		REV. 0303	04-16-2012